ASSEMBLY AND INSTALLATION INSTRUCTIONS

LK34233 / LK34244

WARNING: **TO AVOID RISK OF ELECTRIC SHOCK. BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.**

NOTE: 1.Before installing, consult local electrical codes for wiring and grounding requirements.
2.The combined weight of your ceiling fan and light kit can not exceed 35 pounds unless additional support is provided for the fan.

Fig.1



Fig.2





Installation Steps

1. **Remove the switch box cover from the fan by loosing 3 screws.**
2. **Unscrew and discard the plug from the switch box.**
3. **Attach the light kit to the switch box cover.**
   *****For fans of the Fig.1, attach the nipple of the light kit to the hole of the switch cover, and then thread the wires through the washer and hex nut, secure tightly.**
   *****For fans of the Fig.2, unscrews the 3 screw-1 of the light kit, remove the plate from the light, attach the nipple to the central hole of the switch box cover, and then attach the plate to switch box cover with 2 set screws, install the light fixture to the plate with 3 screws-1.**
4. **Make wire connections with the wire nuts:**
   ---Connect black or blue wire from light kit to blue wire from the fan.
   ---Connect white wire form light kit to white wire from the fan.
   Carefully tuck wires back into the switch box cover.
5. **Reinstall the switch box cover with 3 screws to the fan, attach the glass shade to the lamp holders, and then secure 3 holder screws of the lamp holder .**
6. **Install bulbs.(Please do not exceed the maximum capacity which is recommended on the package.)**
7. **Turn on the power at fuse or circuit box.**

AIRETEK™